



Items 23, 24 and 25 are included in Item 26 (5C Torch Carrier)

○ - Component  
 ⬡ - Assembly

# Model No. 0

Item No.	Part No.	Description	Number
1	2A3&4-0	Ring Gear Assembly	1
2	2-0	Saddle Assembly	1
3	2DP-0	Boomer Strap Eye (Pivot)	1
4	2DL-0	Boomer Strap Eye (Latch)	1
5	20-0	Boomer Strap	1
6	27-0	Boomer (Knurled Knob)	1
7	13K-0	Knurled Thumb Screw	4
8*	13C-0	Cuboid Spacer	4
9	8-0-1	Crank	1
10	8C-0	Crank Pinion	1
11	26-0	Bearing	6
12	8A10&12-0	Crank Gear Axle Assembly	1
13	9-0	Pinion Gear	2
14	18-0	Double Bearing Bracket	1
15	18A-0	Double Bearing Bracket Assembly	1

(Consists of Item Nos. 9,10,11,12,13,14)

Item No.	Part No.	Description	Number
16	14-0	Sprocket	1
17	8A-0	Gear Axle	1
18	17-0	Single Bearing Bracket	1
19	17A-0	Single Bearing Bracket Assembly	1

(Consists of Item Nos. 11,13,16,17,18)

20	12A-0	Top Roller Chain	1
21	23-0	Handle	1
22	1-R	Torch Arm	1
23	7F	Knob and Cam Assembly	1
24	7CS	Torch Holder	1
25	6	Base for 5C	1
26	5C	Torch Carrier Assembly	1
27	30-0	Boomer Assembly	1

(Consists of Item Nos. 3,4,5,6)

\* Cuboid Spacers are used on all Model No. 0 Machines with SN#63337-C4 and up. For all other machines, unless modified with a new saddle, old-style spacers will be required. Order part #36-0 Spacer Bolt Assembly which consists of two spacers each for 2" and 3" pipe.