

## Model No. 2

Item No.	Part No.	Description N	lumber
1	2A3&4-2	Ring Gear Assembly	1
2	2-2	Saddle Assembly	1
3	2DH-1-2	Boomer Strap Eye	1
4	2D-1-2	Boomer Strap Eye	1
5	27-1-6	Boomer	1
6	24-1-2	Boomer Spring	1
7	20-2	Boomer Chain	1
8*	13C-2	Cuboid Spacer	4
9	8-2	Crank	1
10	8C-1-2	Crank Pinion	1
11	26-1-3	Bearing	6
12	8A10&12-1-2	Crank Gear Axle Assembly	1
13	9-2-3	Pinion Gear	2
14	18-2	Double Bearing Bracket	1
15	18A-2	Double Bearing Bracket Assemb	ly 1
(Consist	ts of Item Nos. 9,1	0,11,12,13,14)	

Item No.	Part No.	Description	Number		
16	14-1-2	Sprocket	1		
17	8A-1-3	Gear Axle	1		
18	17-2	Single Bearing Bracket	1		
19	17A-2	Single Bearing Bracket Assemb	ly		
(Consists of items 11,13,16,17,18)					
20	12A-2	Top Roller Chain	1		
21	23-2	Handle	1		
22	1-R	Torch Arm	1		
23	75	Knob and Cam Assembly	1		
24	7CS	Torch Holder	1		
25	6	Base for 5C	Ŧ		
26	5C	Torch Carrier Assembly	1		
27	21-1-2	Key Ring	1		
28	30-2	Boomer Assembly	1		
(Consists of Item Nos. 5,6,7,27)					
29	16-2	Foot	2		

<sup>\*</sup> Cuboid Spacers are used on all Model No. 2 Machines with SN#64709-C12 and up. For all other machines, unless modified with a new saddle, old-style spacers will be required. Order part #36-2 Spacer Bolt Assembly which consists of four spacers each for 8", 10" and 12" pipe.