



Model No. 3

Item No.	Part No.	Description	Number
1	2A3&4-3	Ring Gear Assembly	1
2	2FL-3	Saddle Arm (Left)	1
3	2FR-3	Saddle Arm (Right)	1
4	2E-3	Saddle Spacer Stud	2
5	2C-3	Back Saddle Ring	1
6*	13C-3	Cuboid Spacer	4
7	17AL-3	Single Bearing Bracket Assembly (Left)	1
(Consists of Item Nos. 11, 12, 13, 16, 17)			
8	17AR-3	Single Bearing Bracket Assembly (Right)	1
(Consists of Item Nos. 11, 12, 13, 15, 17)			
9	18A-3	Double Bearing Bracket Assembly	1
(Consists of Item Nos. 12, 14, 18, 19, 20, 21, 33)			
10	29-3	Tie Rod	2
11	14-3	Sprocket	2
12	26-1-3	Bearing	8
13	8B-3	Pinion Gear Axle	2
14	8A-1-3	Gear Axle	1
15	17R-3	Single Bearing Bracket (Right)	1
16	17L-3	Single Bearing Bracket (Left)	1
17	9-2-3	Pinion Gear	2

Item No.	Part No.	Description	Number
18	18-3	Double Bearing Bracket	1
19	12-3	Sprocket (Double)	1
20	10-3	Crank Gear	1
21	8C-3	Crank Pinion	1
22	1-R	Torch Arm	1
23	7F	Knob and Cam Assembly	1
24	7CS	Torch Holder	1
25	6	Base for 5C	1
26	5C	Torch Carrier Assembly	1
27	27-1-6	Boomer	1
28	24-3-6	Boomer Spring	2
29	20-3	Boomer Chain	1
30	21	Boomer Strap Snap	1
31	2D-3-30	Boomer Strap Eye	2
32	12A-3	Top Roller Chain	2
33	8-3-6	Crank	1
34	30-3	Boomer Assembly	1
(Consists of Item Nos. 27, 28, 29, 30)			
35	25	Boomer Hook	1
36	16-3-30	Foot	2

* Cuboid Spacers are used on all Model No. 3 Machines with SN#66260-C20 and up. For all other machines, unless modified with new saddle arms, old-style spacers will be required. Order part #36-3 Spacer Bolt Assembly which consists of four spacers each for 14", 16", 18" and 20" pipe.