



# Model No. 30

Item No.	Part No.	Description	Number
1	2A3&4-30	Ring Gear Assembly	1
2	2FL-30	Saddle Arm (Left)	1
3	2FR-30	Saddle Arm (Right)	1
4*	13C-30	Cuboid Spacer	4
5	2E-30	Saddle Spacer Stud	2
6	27-1-6	Boomer	1
7	24-3-6	Boomer Spring	2
8	20-30	Boomer Chain	1
9	21	Boomer Strap Snap	1
10	2C-30	Back Saddle Ring	1
11	18A-30	Double Bearing Bracket Assembly (Consists of Item Nos. 16,17,18,19,20,21,24,26,30)	2
12	17A-30	Single Bearing Bracket Assembly (Consists of Item Nos. 15,19,20,22,26)	2
13	12B-30	Side Roller Chain	2
14	12A-30	Top Roller Chain	1
15	14-4-6	Sprocket	2
16	10-4-30	Crank Gear	2

Item No.	Part No.	Description	Number
17	8-3-6	Crank	2
18	8C-30	Crank Pinion	2
19	26-4-6	Bearing	12
20	8A-8B-30	Axle	4
21	12-4-6	Sprocket (Double)	2
22	17-30	Single Bearing Bracket	2
23	C-ADJ	Model "C" Adjustable Torch Holder	1
24	18-30	Double Bearing Bracket	2
25	7CS	Torch Holder	1
26	9-4-6	Pinion Gear	4
27	29A-30	Side Tie Rod	2
28	29-30	Tie Rod	1
29	2D-3-30	Boomer Strap Eye	2
30	30-30	Boomer Assembly (Consists of Item Nos. 5,6,7,8)	1
31	25	Boomer Hook	1
32	16-3-30	Foot	2

\* Cuboid Spacers are used on all Model No. 30 Machines with SN#67580-C30 and up. For all other machines, unless modified with new saddle arms, old-style spacers will be required. Order part #36-30 Spacer Bolt Assembly which consists of four spacers each for 26", 28" and 30" pipe.