



○ - Component
 ⬡ - Assembly

Model No. 5

| Item No. | Part No. | Description | Number |
|--|-----------------|---------------------------------|--------|
| 1 | 2A3&4-5 | Ring Gear Assembly | 1 |
| 2 | 2F-5 | Saddle Arm | 2 |
| 3 | 2E-5 | Saddle Spacer Stud | 2 |
| 4 | 2D-5-6 | Boomer Strap Eye | 2 |
| 5 | 2C-5 | Back Saddle Ring | 1 |
| 6* | 13C-5 | Cuboid Spacer | 4 |
| 7 | 18-5-6 | Double Bearing Bracket | 4 |
| 8 | 18AS-5-6 | Double Bearing Bracket Assembly | 2 |
| (Consists of Item Nos. 7,11,12,13,14,15,16,17) | | | |
| 9 | 18AD-5-6 | Double Bearing Bracket Assembly | 2 |
| (Consists of Item Nos. 7,10,11,12,13,14,15,16) | | | |
| 10 | 12-4-6 | Sprocket (Double) | 2 |
| 11 | 10-5-6 | Crank Gear | 4 |
| 12 | 8A-4,5-6-8B-5-6 | Gear Axle | 4 |
| 13 | 26-4-6 | Bearing | 16 |
| 14 | 8C-4,5-6 | Crank Pinion | 4 |
| 15 | 9-4-6 | Pinion Gear | 4 |

| Item No. | Part No. | Description | Number |
|-------------------------------------|----------|-----------------------------------|--------|
| 16 | 8-3-6 | Crank | 2 |
| 17 | 14-4-6 | Sprocket | 2 |
| 18 | 29A-5 | Side Tie Rod | 2 |
| 19 | 29-5 | Tie Rod | 1 |
| 20 | 12B-5 | Side Roller Chain | 2 |
| 21 | 12A-5 | Top Roller Chain | 1 |
| 22 | C-ADJ | Model "C" Adjustable Torch Holder | 1 |
| 23 | 7CS | Torch Holder | 1 |
| 24 | 27-1-6 | Boomer | 1 |
| 25 | 24-3-6 | Boomer Spring | 2 |
| 26 | 20-5 | Boomer Chain | 1 |
| 27 | 21 | Boomer Strap Snap | 1 |
| 28 | 30-5 | Boomer Assembly | 1 |
| (Consists of Item Nos. 25,26,27,28) | | | |
| 29 | 25 | Boomer Hook | 1 |
| 30 | 16-5-6 | Foot | 2 |

* Cuboid Spacers are used on all Model No. 5 Machines with SN#67565-C36 and up. For all other machines, unless modified with new saddle arms,