


30"-48" Heavy Duty Pipe Hook

HOOKHD3048PRO



Component List			
Item	Qty	Description	Part #
1	1	Pipe Hook	PH48-W001
2	1	Backing Pad	PH48-P013
3	4	3/8" Flat Washer	
4	2	3/8"-16 x 2-1/4" Long Hex Bolt	
5	2	3/8"-16 Nylon Lock Nut	
6	1	Identification Tag A	PH48-P017
7	1	Identification Tag B	PH48-P018

Inspection Checklist:	Verified	Notes
Pull test certificate	<input type="checkbox"/>	Certificate #:
Identification tag(s) present and legible	<input type="checkbox"/>	
All components are present	<input type="checkbox"/>	
Visually inspect all components for damage, cracks, corrosion, etc.	<input type="checkbox"/>	
All fasteners are secure/tight	<input type="checkbox"/>	
	<input type="checkbox"/>	
	<input type="checkbox"/>	

Inspected By:
Date:

Serial Number:
Signature:

Recommended Customer Inspection Checklist

ASME B30.20 requires the end user to perform inspections on the lifting equipment, categorized into three classifications: Every Lift, Frequent, and Periodic. The time intervals of Frequent and Periodic inspections can vary depending on the type of usage of the equipment. Assuming 'normal' service, Proline has created a recommended customer inspection checklist that is suggested to be used as a minimum requirement. Periodic (Annual) inspections must be dated and recorded.

It is the responsibility of the end user to ensure compliance with any applicable standards or codes.

Description	Every Lift	Monthly	Annually
Visually inspect hook for damage, wear, cracks, etc.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Ensure Identification tags are present and legible	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Visually inspect backing pad		<input type="checkbox"/>	<input type="checkbox"/>
Ensure all fasteners are secure		<input type="checkbox"/>	<input type="checkbox"/>
Magnetic Particle Inspection			<input type="checkbox"/>
Pull test to 200% SWL			<input type="checkbox"/>

Notes:

Serial Number:

Date of Annual Inspection:

Name of Inspector:

Signature of Inspector: